

## Hyundai Ioniq AE-EV (Model Year 2016–2019 EM09 / 88 KW)



The content of this brochure shall not be legally binding and is for information purposes only. To the extent legally permissible, Schaeffler Automotive Aftermarket GmbH & Co. KG assumes no liability out of or in connection with this brochure.

Schaeffler Automotive Aftermarket GmbH & Co. KG  
August 2024

All rights reserved. Any copying, distribution, reproduction, making publicly available or other publication of this brochure in whole or in extracts without the prior written consent of Schaeffler Automotive Aftermarket GmbH & Co. KG is prohibited.  
Copyright ©

## Schaeffler in the Automotive Aftermarket – more innovation, more quality and more service.

### Schaeffler in the Automotive Aftermarket – always the first choice for vehicle repair.

Whenever a vehicle needs to go to the garage, our products and repair solutions are first choice to fix them. With our system competence in transmission, engine, and chassis, we are a reliable partner around the world. Whether passenger cars, light and heavy commercial vehicles, or tractors – our optimally tuned components allow fast and professional parts replacement.

Our products are based on a comprehensive systems approach. Innovation, technical expertise, and the highest material and manufacturing quality make us not only one of the leading development partners for vehicle manufacturers, but also a pioneering provider of value-retaining spare parts and complete repair solutions for clutches and clutch release systems, engine and transmission applications, and chassis applications in original-equipment quality – right up to the appropriate special tools.

### Schaeffler REPERT – the service brand for garage professionals.

SCHAEFFLER  
**REPERT**

With REPERT, we offer a comprehensive service package for our products and repair solutions. Looking for specific information about damage diagnosis?

Are you in need of particular tools to help make your everyday garage routine easier? Whether online portal, service hotline, installation instructions and videos, training seminars, or events – you get all technical services from a single source.

Register now for free, in just a few clicks, at:  
**[www.repxpert.com](http://www.repxpert.com)**.



## Hyundai Ioniq AE-EV disassembly and assembly

- The vehicle manufacturer's specifications and safety instructions must be observed when removing and installing the drive unit
- Work on electric vehicles may only be carried out in compliance with the country-specific legal regulations
- Repairs may only be carried out by specialist staff and using suitable garage equipment
- The bearing seats and the seats of the shaft seals need to be cleaned
- The inner and outer bearing races must not be interchanged
- Cleanliness must be ensured throughout the entire repair process
- When using thread lock or bolt sealant, it is necessary to clean the threads before application



- Drain the transmission oil
- Tighten the oil drain plug to 52 Nm
- Remove the gearbox in accordance with the vehicle manufacturer's specifications
- Disassemble attachment parts such as the gearbox suspension, etc.



- Remove the bolts and lift the parking lock actuator upwards



- Remove the gearbox-side shaft seal of the drive shaft

**Note:**

The disassembly tool must **not** be placed in the 12 or 6 o'clock positions in relation to the installation position in the vehicle as there are oil ducts in these positions



- Remove the motor-side shaft seal of the drive shaft

**Note:**

The disassembly tool must not be placed in the 12 or 6 o'clock positions in relation to the installation position in the vehicle as there are oil ducts in these positions



- Remove the first bolt for the parking lock






- Place the gearbox on the motor mounting surface
- Remove the second bolt for the parking lock




- Disassemble the gearbox housing bolts
- Lift the gearbox housing evenly upwards, using appropriate tools (e.g., mounting lever)



- Remove the two adjusting shims from the input and output shaft




- Remove the differential gear




- Remove the input and output shaft



- Remove the magnet




- Remove the input shaft oil seal



- Remove the motor-side bearing outer race in the gearbox housing using a suitable internal extractor



- Clean off all old residual sealant
- Clean the motor side housing






- Press the new motor-side bearing outer race into the gearbox housing



- Press in the new input shaft oil seal

**Note:**


Pay attention to the installation position




- Remove the gearbox-side bearing outer race in the gearbox housing using a suitable internal extractor

**Note:**


An adjusting shim is located under the bearing outer ring




- Clean off all old residual sealant
- Clean the gearbox side housing



- Unscrew the bolt for the parking lock shaft




- Remove the shaft




- Remove the shaft seal with a suitable internal extractor
- Ensure the puller only to grip the shaft seal and not the needle roller bearing underneath

**Note:**


Note the installation depth of the shaft seal ring



- Assemble a new shaft seal at the previous installation depth



- Installing the parking lock mechanism
- Insert the shaft bolt and tighten to 10 Nm





- Press a gearbox-side new outer bearing race **without an adjusting shim** into the gearbox housing

**Please note:**


The correct adjusting shim is not determined until a later work step and then assembled




- Press off the motor-side bearing for the input shaft




- Press off the gearbox-side bearing for the input shaft



- Press on the new gearbox-side bearing for the input shaft



- Press on the new motor-side bearing for the input shaft



- Press off the motor-side bearing for the output shaft






- Press on the new motor-side bearing for the output shaft



- Press off the gearbox-side bearing for the output shaft




- Press on the new gearbox-side bearing for the output shaft



- Pull off the motor-side tapered roller bearing from the differential gear




- Press the new motor-side tapered roller bearing onto the differential gear




- Press off the gearbox-side tapered roller bearing from the differential gear



- Place the intermediate plate as shown in the image



- Press the new gearbox-side tapered roller bearing onto the differential gear



- Motor housing side:  
Measure the distance between the sealing surface and the bearing seat of the output shaft at four points using a depth caliper and two flat rulers and calculate the average value

**For example:**

$$\frac{(55.48 + 55.46 + 55.48 + 55.47) \text{ mm}}{4} = 55.47 \text{ mm}$$

**Note:**

The thickness of the flat rulers must be removed from the calculation



- Gearbox housing side:

Measure the distance between the sealing surface and the bearing seat of the output shaft at four points using a depth caliper and two flat rulers and calculate the average value

**For example:**

$$\frac{(62.73 + 62.73 + 62.72 + 62.74) \text{ mm}}{4} = 62.73 \text{ mm}$$

**Note:**

The thickness of the flat rulers must be removed from the calculation



- Place the existing adjusting shim of the output shaft together with the output shaft on a suitable measuring plate



- Place any adjusting shim that fits the upper bearing of the output shaft on a measuring plate
- Measure the thickness of the adjusting shim with a depth caliper and set the depth caliper to “zero”





- Place the adjusting shim from the previous step onto the upper bearing of the output shaft
- Measure the distance between the bearing outer rings, including the two adjusting shims

■ **For example:** 118.26 mm



- The nominal value of the bearing play is **0.00 mm to 0.08 mm**

- **Calculate the existing bearing setting:**

Motor housing side distance  
+ gearbox housing side distance  


---

= distance between bearing seats

Distance between bearing seats  
- distance between bearing outer rings  


---

= existing bearing setting

**Note:**

Negative value (-) = preload  
positive value (+) = clearance



- **Example:**

55.47 mm  
+ 62.73 mm  


---

= 118.20 mm

118.20 mm  
- 118.26 mm  


---

= - 0.06 mm (preload)

- If the determined value is outside the above target value, the required bearing play has to be adapted by replacing the adjusting shim







- In our example, the existing adjusting shim (1.02 mm) would have to be 0.06 mm to 0.14 mm thinner
- The new adjusting shim would then have a thickness of 0.96 mm to 0.88 mm

**Note:**

Information on the adjusting shims can be found in the appendix

- The adjusting shim determined is placed in the gearbox housing at a later time
- Place the differential gear and input shaft **without** an adjusting shim in the motor housing
- Put on the housing cover and tighten all bolts to 15 Nm



- Turn the gearbox over
- Mount the dial gauge as shown, place the measuring tip on the input shaft, and make sure of the preload



- Pull the input shaft up to the stop by hand and read off and note the value

■ **For example:** 2.77 mm



- The nominal value of the bearing play is **0.00 mm to 0.06 mm**

- **Determine the correct adjusting shim:**

Value from previous step  
– bearing play  
—  
= thickness of adjusting shim



- **Example:**

$$\begin{array}{r} 2.77 \text{ mm} \\ - 0.00 \text{ mm to } 0.06 \text{ mm} \\ \hline = 2.77 \text{ mm to } 2.71 \text{ mm} \end{array}$$

- The adjusting shim determined is placed in the gearbox-side housing at a later time

**Note:**

Information on the adjusting shims can be found in the appendix




- Disassemble the dial gauge, assemble it as shown for another measurement, place the measuring tip on the bearing inner ring of the differential, and make sure of the preload



- Pull the differential up to the stop by hand and read off and note the value

■ **For example:** 0.81 mm



- The nominal value of the bearing preload is **0.10 mm to 0.16 mm**

- **Determine the correct adjusting shim:**

Value from previous step  
 + bearing play  


---

 = thickness of adjusting shim



- **Example:**

0.81 mm  
 + 0.10 mm to 0.16 mm  


---

 = 0.91 mm to 0.97 mm


- The adjusting shim determined is placed in the gearbox-side housing at a later time

**Note:**

Information on the adjusting shims can be found in the appendix




- Disassemble the dial gauge
- Place the gearbox on the motor side
- Remove the gearbox housing bolts
- Lift the gearbox housing evenly up and off with a suitable tool (e.g., mounting lever)



- Remove the input shaft and differential gear from the housing



- Remove the gearbox-side bearing outer race in the gearbox housing using a suitable internal extractor



- Insert the previously determined adjusting shim for the differential gear






- Press the gearbox-side bearing outer race back into the gearbox housing



- Press in the red, gearbox side drive shaft seal

**Note:**


The drive shaft seals are different and must not be interchanged




- Press in the blue, motor side drive shaft oil seal



- Insert the input shaft and output shaft into the housing



- Insert the differential gear into the housing




- Clean the magnet
- Place the magnet in the housing



- Clean the sealing surfaces with a suitable cleaner, such as Loctite SF 7063
- Apply a suitable sealant, such as Loctite 510, to the housing

**Note:**


Ensure that the alignment dowels sleeves are correctly positioned in the housing



- Place the previously determined adjusting shims for the input and output shaft onto the bearings



- Assemble the gearbox housing cover and tighten the bolts to 25 Nm





- Clean the first bolt for the parking lock
- Put on the new sealing shim
- Apply thread sealant, such as Loctite 577
- Tighten the bolt to 25 Nm



- Clean the second bolt for the parking lock
- Put on the new sealing shim
- Apply thread sealant, such as Loctite 577
- Tighten the bolt to 25 Nm



- Assemble the parking lock actuator and tighten the bolts to 24 Nm



- Remove the O-ring for the rotor shaft
- Clean the rotor shaft splines
- Replace the O-ring
- Apply grease to the rotor shaft splines (e.g., CASMOLY L9508)



- Install the gearbox, observing the vehicle manufacturer's instructions
- Gear oil quantity: 1.0 to 1.1 liters
- Oil specification: 70W, API GL-4, TGO-9 (MS517-14)
- Tightening torque of the oil level bolts: 52 Nm
- Tightening torque of the fastening bolts for the gearbox and electric motor: 47 Nm





## APPENDIX

### Set of adjusting shims for output shaft bearing

Art. no. 464 0026 10

Shim thickness:
0.60 mm
0.65 mm
0.70 mm
0.75 mm
0.80 mm
0.85 mm
0.90 mm
0.95 mm
1.00 mm
1.05 mm
1.10 mm
1.15 mm
1.20 mm
1.25 mm
1.30 mm
1.35 mm
1.40 mm
1.45 mm
1.50 mm
1.55 mm
1.60 mm

### Set of adjusting shims for input shaft bearing

Art. no. 464 0025 10

Shim thickness:
2.20 mm
2.25 mm
2.30 mm
2.35 mm
2.40 mm
2.45 mm
2.50 mm
2.55 mm
2.60 mm
2.65 mm
2.70 mm
2.75 mm
2.80 mm
2.85 mm
2.90 mm
2.95 mm
3.00 mm
3.05 mm
3.10 mm
3.15 mm
3.20 mm

**Set of adjusting shims for differential gear bearing**

Art. no. 464 0027 10

<b>Shim thickness:</b>
0.60 mm
0.65 mm
0.70 mm
0.75 mm
0.80 mm
0.85 mm
0.90 mm
0.95 mm
1.00 mm
1.05 mm
1.10 mm
1.15 mm
1.20 mm
1.25 mm
1.30 mm
1.35 mm
1.40 mm
1.45 mm
1.50 mm
1.55 mm
1.60 mm



If individual adjusting shims are required to supplement the respective set,  
These can be ordered at <https://www.rexpert.com/repssystem-g-shims>.

