

Einbauanleitung

Fitting instructions

Istruzioni di montaggio

Notice de montage

Instrucciones de montaje

Monteringsanvisning

CORTECO

BMW 1er/1 series (E81-E87)
BMW 1er/1 series (E82) Coupe
BMW 1er/1 series (E88)
BMW 3er/3 series (E90;E91)
BMW X1 (E84)

8000063

8000064

09.04 →

10.07 →

03.08 →

01.05 →

10.09 →



The Perfect Change.

< 10 min

