



filter NC2385

FIAT Panda (12→)
FIAT 500 (07→)
LANCIA Ypsilon (11→)

Per il montaggio procedere eseguendo le operazioni in senso inverso.
Continuomounting in reverse order of operations
 Le remontage s'effectue dans l'ordre inverse.
Der weitere Einbau erfolgt in umgekehrter Reihenfolge
 Para concluir la instalación, seguir el orden inverso.

