

# **FORD**

*Mondeo III 2000-*

## **FSK 6410 / FSK 6411** **Ford Mondeo III rear subframe bushes**

### **SPECIAL INSTRUCTIONS & FITTING TIPS**

Thoroughly clean the mounting holes in the subframe prior to installation of the new bushes.

Apply **Loctite270** © to the outer circumference of the bush and ensure that it is correctly aligned before pressing in.

### **IMPORTANT NOTE**

The vehicle may be moved but must not be driven for 24hrs to allow the **Loctite 270** © to fully cure.

First Line recommend that the subframe bushes are replaced as a full set.



**FSK 6410**  
Front 'V Shaped' head



**FSK 6411**  
Rear straight head