

Universaldamask *Universal CV-Boot*



CDX
DRIVELINE
Monteringsanvisning
Mounting instruction

- Demontera drivknuten och rengör noga drivaxeln och drivknuten från fett och smuts.



Dismount the CV-Joint and thoroughly remove grease and dirt from the driveshaft and the CV-Joint.

- Skär av damasken till lämplig diameter för drivaxeln och drivknut.
- Trä på damasken på drivaxeln.
- Montera tillbaka drivknuten på drivaxeln. Det är viktigt att gängor och splines inte skadas vid monteringen.
- Applicera det medföljande fettet i damasken.

Cut the boot to suitable diameter for driveshaft and CV-Joint.

Slide the boot over the driveshaft.

Mount the CV-Joint back on the driveshaft. It is important not to damage threads and splines when mounting the CV-Joint.

Apply the enclosed grease into the CV-Boot.



- Dra damasken över drivknuten.

Slide the boot over the CV-Joint.



- Fäst damasken med medföljande klammer på drivknut och drivaxel.



Fasten the boot with the enclosed clamps on the CV-Joint and driveshaft.