

## Gewindefahrwerk 28797-1

**Warnung:** Nichtbeachtung dieser Einbauanweisung kann zu Schäden am Fahrzeug und zu Personenschäden führen. In diesem Fall weist H&R jegliche Verantwortung zurück.

**Achtung:** Nach dem Umbau sind Spur, Sturz und die Scheinwerfereinstellung gemäß Werkstattangaben zu kontrollieren bzw. einzustellen.

**Hinweis:** Einbauanweisungen ersetzen nicht das Werkstatthandbuch des Fahrzeugherstellers; sie erheben keinen Anspruch auf Vollständigkeit und/oder Berücksichtigung aller möglichen Toleranzen und Fehlerquellen.

### Vorderachse:

- Der **Anschlagpuffer** ist bereits im Dämpfer verbaut, der Serienpuffer darf nicht verwendet werden.
- **Einstellmaß VA:**  
190 - 215 mm
- Das **Schutzrohr** (Einheit Schutzrohr - Federunterlage) muss an der obersten Rille abgeschnitten werden, der abgeschnittene obere Teil muss dann wieder verbaut werden.

### Hinterachse:

- Der serienmäßige **Anschlagpuffer** muss wieder verwendet werden.
- **Einstellmaß HA:**  
35 - 60 mm
- Die serienmäßige obere (karosserie-seitige) Federauflage entfällt. Stattdessen wird die **Hinterachshöhenverstellung** verbaut.



**Bild 1:** Einstellmaß VA  
(Abbildung ähnlich)



**Bild 2:** Einstellmaß HA  
(Abbildung ähnlich)



**Bild 3:** Schutzrohr gekürzt  
(Abbildung ähnlich)

### Coil over suspension 28797-1

**Warning:** Any non-observance of these installation instructions might lead to damage of the car and injury of persons. In this case H&R rejects any responsibility.

**Attention:** After installation wheel alignment and brake-power regulator have to be checked and adjusted to the factory specifications if necessary. Headlights also have to be checked and adjusted if necessary.

**Note:** Installation instructions do not replace the vehicle manufacturer's handbook; they do not claim to cover complete fitment and/or to regard every possible tolerance or source of error.

#### Front axle:

- The **bump rubber** is fitted within the shock absorber. Do not use the OE rubber.
- **Adjustment dimension FA:**  
*190 - 215 mm*
- The **dust cover** has to be cut at the upper groove; install the cut upper part again

#### Rear axle:

- The OE **bump rubber** has to be reused.
- **Adjustment dimension RA:**  
*35 - 60 mm*
- The upper OE spring plate must not be used. Instead of that, the rear **height adjuster** is installed.



**Pic 1:** FA spring plate adjustment dimension  
(Picture may vary)



**Pic 2:** RA spring plate adjustment dimension  
(Picture may vary)



**Pic 3:** Dust cover shortened  
(Picture may vary)