



# Fitting Instructions

TOWBAR CH6A  
For CHRYSLER CHEROKEE JEEP  
1997- 2001

## MATERIALS

A	1	Cross Bar with European facing to 94/20/EC - A50-1
D	8	M12 x 50 x 1.75mm Bolts, Lock Washers and Large Flat Washers (30mm O.D.)
E	2	Side Arms (1 left hand, 1 right hand)
F	2	M12 x 25 x 1.75mm Bolts, Lock Washers and Flat Washers (30mm O.D.)
F1	1	Spreader Plate
G	6	M12 x 30 x 1.75mm Bolts, Lock Washers and 4 Nuts
H	2	M12 x 1.75mm Nuts
CB	2	M16 x 50 x 2.0mm Coupling Bolts, Nuts and Lock Washers
Z	1	ZEP35 Electrical plate (not shown)

## FITTING

1. Remove and discard towing eye bracket. Also remove rearmost exhaust hanger bracket and 2 studs from chassis using 8mm ring spanner. Note: In extreme cases studs may be left in place and Nuts (H) can be used.
2. Loosely attach Side Arms (E) to vehicle chassis using Bolts (D). On right hand side re-mount exhaust hanger along with Side Arm (E).
3. Loosely attach Cross Bar (A) to Side Arms (E) using Bolts (G). Also attach Cross Bar (A) to rear cross member using Bolts (F) with Spreader Plate (F1) on rear face. **NOTE:** It may be necessary to loosen bumper to gain access to Bolts (F).
4. Tighten all bolts.

**Note:** This towbar must be used with either a Witter Towball (part number Z1X) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

