



Fitting Instructions

DETACHABLE TOWBAR
For **MITSUBISHI SHOGUN**
SWB
(2007-)

CL100BU

MATERIALS

A	1	Cross Bar
D	4	M12 x 30 x 1.25mm Fine Pitch Bolts, Nuts and Lock Washers
E	2	Side Plates
F	1	Right Hand Side Arm
G	1	Left Hand Side Arm
H	2	M12 x 110 x 1.25mm Fine Pitch Bolts, Nuts, Lock Washers and Flat Washers (30mm O.D.)
J	8	M12 x 30 x 1.25mm Fine Pitch Bolts, Lock Washers and Flat Washers (30mm O.D.)
K	6	M12 x 35 x 1.75mm Bolts and 4 Nyloc Nuts
ZEP	1	Electrical Plate (ZEP2)
ZQ	1	Detachable Neck Kit (ZQ2034)

FITTING

1. Remove one piece towing eye bracket (4 bolts each side and bolts on lower edge of bumper). Loosely attach Side Arms (F) and (G) to Side Plates (E) using Bolts (D).
2. Loosely attach Side Plates (E) to inside faces of chassis using 1 Bolt (J) each side and Bolts (H). Attach Side Arms (F) and (G) to underside of chassis using Bolts (J).
3. Loosely attach Cross Bar (A) to Side Plates (E) using Bolts (K). Attach Detachable Neck Kit (ZQ) and Electrical Plate (ZEP) Cross Bar (A) as per separate instruction. Tighten all bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

