



Fitting Instructions

TOWBAR CL84CU
For MITSUBISHI SHOGUN LWB
(2000-)
For use with ZQ2034 Neck Only.

MATERIALS

A	1	Cross Bar
D	6	M12 x 30 x 1.25mm Fine Pitch Bolts, Nuts and Lock Washers
E	2	Side Plates
F	2	Cleats (4 holes)
G	2	Cleats (2 holes)
H	4	M12 x 110 x 1.25mm Fine Pitch Bolts, Lock Washers and Flat Washers (30mm O.D.)
J	4	Nut Straps
K	8	M12 x 30 x 1.25mm Fine Pitch Bolts, Lock Washers and Flat Washers (30mm O.D.)
L	6	M12 x 35 x 1.75mm Standard Pitch Bolts and Nyloc Nuts
M	4	M6 x 20 x 1.0mm Bolts, Nuts, Lock Washers and Flat Washers
ZEP	1	Electrical Plate (ZEP2)

FITTING

*** NOTE THIS TOWBAR HAS DIFFERENT THREAD PITCHES WITHIN THE BOLT KIT, ENSURE CORRECT PITCH IS USED FOR EACH SECTION OF THE FITTING ***

1. Temporarily lower gas can on right hand side (4 vertical M6 bolts). Remove one piece towing eye bracket (4 bolts each side and bolts on lower edge of bumper).
2. Loosely attach Cleats (F) and (G) to Side Plates (E) using Bolts (D). NOTE: Ensure Bolts (D) are fitted with heads on inboard face of Side Plates (E).
3. Loosely attach Side Plates (E) to inside faces of chassis using 1 Bolt (K) each side, also Bolts (H) and Nut Straps (J). Attach Cleats (F) and (G) to underside of chassis using Bolts (K).
4. Loosely attach Cross Bar (A) to Side Plates (E) using Bolts (L). Attach Detachable Neck Kit (ZQ2034) and Electrical Plate (ZEP) to Cross Bar (A) as per separate instructions. Tighten all bolts. Re-attach bumper using Bolts (M).

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

