

**TOYOTA CAMRY SEDAN 10/11 – 08/17**  
**TOYOTA AURION SEDAN 03/12 – 08/17**

PART NO.

**UNT298**

1. In vehicle's boot, remove the following parts:
  - a. Boot floor carpet
  - b. LHS underfloor tool storage compartment
  - c. LHS boot trim. Remove cargo hook and 2x plastic scrivenets
2. Locate 8 pin vehicle connector and disconnect
3. Connect trailer harness plugs in between vehicle plugs
4. Mount ECU using double sided tape supplied
5. Route five core cable to trailer socket mounting position. Make sure cable is securely attached using zip ties or similar (not supplied) and maintains a safe distance from heat or sharp edges.
6. Replace all parts removed in the reverse order as above.

