

## Replacing SAC design clutch with conventional aftermarket replacement.

The enclosed parts <u>differ in appearance</u> to the original equipment design.



We have carried out stringent testing and evaluation to ensure the units are suitable alternatives.



## **Dual mass flywheel identification on Mercedes Sprinter**

Due to o/e design changes, there are two different depth flywheels fitted between 2000 -> 2006.

