


How to detach the blade

- 1 Stand the wiper arm.





- 2 Rotate the blade and make proper angle to detach the blade.

**Do not detach it forcibly!*

How to attach the blade

- 1 Insert Center bar into tip of Wiper Arm, "B".



- 2 Set the blade so that Bump is located in the bottom of Center bar.

- 3 Rotate the blade and make proper angle so that Center bar can go into "B" smoothly.

- 4 After inserting the blade to the depths,

1. Rotate the blade as shown in the instruction.
2. Check if the blade is fixed with wiper arm correctly.

