



## Removal of Seal Protection Tube

The Concentric Slave Cylinder supplied in this kit may have a plastic cap and/ or seal protection tube to prevent damage during installation. Some examples are pictured below.

**Plastic Cap For Hydraulic Line**



**Plastic Seal Protection Tube**



Without removing any of the plastic caps or protection tube, carefully slide the concentric slave cylinder over the input shaft. Once the back seal is over the spline the seal protection tube can be removed. This protects the seal from being damaged on the spline.

Leave the plastic cap in until the gearbox is mated to the engine to prevent any contamination or debris entering the hydraulic system.

### LEADING BRANDS

**CLUTCHPRO CLUTCHPRO**  
RACING MATERIAL



[australianclutch.com.au](http://australianclutch.com.au)

1800 CLUTCH (258824)