


RYCO FILTERS



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA240P/MS.
HYUNDAI I30 FD



1. The cabin air filter housing is located behind the glove box compartment. It has to be removed to gain access.
2. Open the glove box and press both top corners inwards to bypass the retaining lugs then, while holding the lid un-hinge the strut on the side of the box facing the door. Slowly drop the glove box compartment completely.
3. Remove the cabin air filter housing lid by unclipping it and slide out the old cabin air filter carefully to avoid any accumulated debris from being spread around.
4. Clean the area and slide in the new filter making sure it is facing in the right air flow direction marked on the side of the filter and refit all components in reverse order.


GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

GUD Automotive -
A division of GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz

RYCO FILTERS



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA240P/MS.
HYUNDAI I30 FD



1. The cabin air filter housing is located behind the glove box compartment. It has to be removed to gain access.
2. Open the glove box and press both top corners inwards to bypass the retaining lugs then, while holding the lid un-hinge the strut on the side of the box facing the door. Slowly drop the glove box compartment completely.
3. Remove the cabin air filter housing lid by unclipping it and slide out the old cabin air filter carefully to avoid any accumulated debris from being spread around.
4. Clean the area and slide in the new filter making sure it is facing in the right air flow direction marked on the side of the filter and refit all components in reverse order.

GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

GUD Automotive -
A division of GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz