



RYCO

F I L T E R S

FITTING INSTRUCTIONS FOR A MAZDA 2 (DE) RYCO CABIN AIR FILTER RCA246P



The cabin air filter location is on the drivers side footwell at the far end of the centre console. To access the filter undo the 4 screws shown in the picture with a Phillips screw driver and remove the housing lid.



Once the cabin air filter housing lid is out of the way, the filter will be accesible. Pull the first filter out and then reach for the second one. Pay attention on how the filters sit in and replicate this with the new ones, making sure they are placed in the right air flow direction and lastly refit the housing lid.


GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia
www.rycofilters.com.au

GUD Automotive - A Division of
GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz


RYCO

F I L T E R S

FITTING INSTRUCTIONS FOR A MAZDA 2 (DE) RYCO CABIN AIR FILTER RCA246P



The cabin air filter location is on the drivers side footwell at the far end of the centre console. To access the filter undo the 4 screws shown in the picture with a Phillips screw driver and remove the housing lid.



Once the cabin air filter housing lid is out of the way, the filter will be accesible. Pull the first filter out and then reach for the second one. Pay attention on how the filters sit in and replicate this with the new ones, making sure they are placed in the right air flow direction and lastly refit the housing lid.

GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia
www.rycofilters.com.au

GUD Automotive - A Division of
GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz