

| Product info sh | neet | Denso | DCRI106250 | |
|--|--------------|-------------------------------|-------------------------------|--|
| Special tools needed? | No | | | |
| Attention! Write down the readible after mounting or | | code before mounting. Possibl | y not | |
| | Pr | oduct specific info | rmation | |
| Programming | Yes | ID code (30 characters) | 6114.0512 | |
| | | | 90,855 1717 4215 1415 2AIB | |
| Unlocking | No | | 3,000,0 | |
| Adaption values reset | Yes | Reset adaptive values | | |
| Bleed | Yes | Use manual pump on ve | hicle | |
| adjustment at mounting_1 | | | | |
| | | T. 1 | | |
| luis stou/ notoinin salama | | Tightening torq | ues | |
| Injector/ retainingclamp High Pressure pipe nuts | | | 33 Nm | |
| Banjo fuel fitting | | 18 Nm | | |
| bunjo ruei memg | | | | |
| | | | A | |
| | | | | |
| | | Assembly instruc | tions | |
| Recommendation: replace Replace sealing washer Recommendation: replace | | | | |
| песопппениацоп, геріасе | Jeaning Hill | | | |
| Core charge terms: | | | | |
| -externally intact,-no mechanical damage, | | | | |
| -not dismantled, | | | | |
| -no heavy corrosion. | | | | |