




Tightening torque

700 Nm



Please check tightening torques regularly!

Use a torque spanner to ensure that the specified torques are accurately maintained.



If the wheels were off, check and re-tighten the wheel nuts after about 50 - 100 km of driving.