## **LED Shine Spot**

## **Holder, hand lamp**

The telescopic bonnet mounting is equipped with two holders for the LED Shine Spot hand lamp (hand lamps not included in scope of supply). The holders can be moved horizontally along the guide rail of the telescopic bar and

fixed in place. The bracket also rotates 360° around its own axis. Thanks to a recess, the hand lamp can be easily secured to the holder and simply removed from the bracket whenever necessary.

DU	Article no.
1	99910163001







