

NEW PRODUCT HIGHLIGHT | JAN2021 SWAG 20 10 8217

SWAG[®]

To Fit:

BMW 1 series (E82, E88), 3 series
(E90, E91, E92, E93), 5 series (E60, E61),
X1 (E84), X5 (E70), X6 (E71)



EN

Button for tailgate

Function

When the external tailgate/luggage compartment release switch is depressed, the switch completes the circuit. The tailgate release actuator then receives a release signal from the Body Control Module and the tailgate/luggage compartment is then able to be opened.

Cause of failure

If the external release switch fails, the rear tailgate/luggage compartment can only be opened by using the remote key, or the switch inside the vehicle.

Possible failure causes include:

On some of the above models the rear screen washer jet becomes blocked, which causes the water pipe to come unattached when under pressure. The washer fluid then leaks onto the electrical components and causes corrosion of the electrical connectors.

The outer plastic can perish and split over time, allowing road spray to enter the mechanism causing the switch to fail.

For more technical information please visit: partsfinder.bilsteingroup.com