



## ALTERNATEUR IVECO



Remanufactured

Core code : 06

FAHAAM



3599771209011



## TECHNICAL DATA

Alternator Charging Current [A]	<b>55 A</b>
Fiche	<b>PLUG632</b>
Pulleys	<b>without belt pulley</b>
Info complémentaire	<b>with integrated regulator</b>
Connector/Clamp	<b>with connection for speed sensor</b>
Clamp	<b>M8 B+</b>
Voltage [V]	<b>24 V</b>

## PICTURES



Before installation, compare the part received with the original part to ensure that the correct part number has been selected and can be installed on the vehicle. Failure to follow those, or the manufacturer, instructions will void the warranty.

<b>IVECO</b>		
EUROCARGO I-III - 60 E 10	102 ch	01.1991 > 09.2015
EUROCARGO I-III - 60 E 12	116 ch	01.1991 > 09.2015
EUROCARGO I-III - 60 E 14, 60 E 14 P	136 ch	01.1991 > 09.2015
EUROCARGO I-III - 60 E 14 K	136 ch	01.1991 > 09.2015
EUROCARGO I-III - 65 E 10	102 ch	01.1991 > 09.2015
EUROCARGO I-III - 65 E 10 K	102 ch	01.1991 > 09.2015
EUROCARGO I-III - 65 E 12, 65 E 12 P	116 ch	01.1991 > 09.2015
EUROCARGO I-III - 65 E 12 K	116 ch	01.1991 > 09.2015
EUROCARGO I-III - 65 E 14, 65 E 14 P	136 ch	01.1991 > 09.2015
EUROCARGO I-III - 65 E 14 K	136 ch	01.1991 > 09.2015
EUROCARGO I-III - 75 E 12, 75 E 12 P	116 ch	01.1991 > 09.2015
EUROCARGO I-III - 75 E 14, 75 E 14 P	136 ch	01.1991 > 09.2015
EUROCARGO I-III - 75 E 15, 75 E 15 P, 80 E 15	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 75 E 15 K	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 80 E 15 K	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 80 E 15, 80 E 15 P	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 80 E 15 K	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 80 E 18, 80 E 18 P, 18 E 80 FP	177 ch	01.1991 > 09.2015
	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 80 E 18 K	177 ch	01.1991 > 09.2015
	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 80 E 21, 80 E 21 P, 80 E 21 FP	207 ch	01.1991 > 09.2015
EUROCARGO I-III - 80 E 21, 80 E 21 P, 21 E 80 FP	207 ch	01.1991 > 09.2015
EUROCARGO I-III - 95 E 15 W	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 95 E 21 W	207 ch	<b>11.1993 &gt; 09.2015</b>
EUROCARGO I-III - 100 E 15, 100 E 15 P	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 100 E 15 K	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 100 E 18, 100 E 18 P	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 100 E 18 K	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 100 E 21, 100 E 21 P	207 ch	01.1991 > 09.2015
EUROCARGO I-III - 120 E 15	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 120 E 15 K	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 120 E 18, 120 E 18 P, 120 E 18 H	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 120 E 18 K	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 120 E 23, 120 E 23 P, 120 E 23 FP, 120 E 23 H	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 130 E 15	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 130 E 15 K	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 130 E 18	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 130 E 18 K	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 130 E 23	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 135 E 18 W	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 135 E 18 WR	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 135 E 23 W	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 135 E 23 WR	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 150 E 15	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 150 E 15 K	143 ch	01.1991 > 09.2015
EUROCARGO I-III - 150 E 18, 150 E 18 P	175 ch	01.1991 > 09.2015
EUROCARGO I-III - 150 E 18 K	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 150 E 23, 150 E 23 P, 150 E 23 FP	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 150 E 27, 150 E 27 P, 150 E27FP, 150 E 27 R	267 ch	01.1991 > 09.2015
EUROCARGO I-III - 170 E 18, 180 E 18	177 ch	01.1991 > 09.2015

<b>IVECO</b>		
EUROCARGO I-III - 170 E 18 K, 180 E 18 K	177 ch	01.1991 > 09.2015
EUROCARGO I-III - 170 E 23,180 E 23	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 170 E 23 K,180 E 23 K	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 170 E 27,180 E 27	267 ch	01.1991 > 09.2015
EUROCARGO I-III - 180 E 21 T	207 ch	01.1991 > 09.2015
EUROCARGO I-III - 260 E 23 T	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 280 E 23 T	227 ch	01.1991 > 09.2015
EUROCARGO I-III - 320 E 27 T	267 ch	01.1991 > 09.2015
EUROSTAR - LD 190 E 38 P	375 ch	01.1993 > 02.2002
EUROSTAR - LD 190 E 42, LD 190 E 42 P	420 ch	01.1993 > 02.2002
EUROSTAR - LD 190 E 47	469 ch	01.1993 > 02.2002
EUROSTAR - LD 190 E 52	514 ch	01.1993 > 02.2002
EUROSTAR - LD 240 E 38	375 ch	01.1993 > 02.2002
EUROSTAR - LD 240 E 42 FS, LD 240 E 42 PS	420 ch	01.1993 > 02.2002
EUROSTAR - LD 240 E 47 PS	469 ch	01.1993 > 02.2002
EUROSTAR - LD 240 E 52 PS	514 ch	01.1993 > 02.2002
EUROSTAR - LD 260 E 38 P	375 ch	01.1993 > 02.2002
EUROSTAR - LD 260 E 42 P	420 ch	01.1993 > 02.2002
EUROSTAR - LD 260 E 47	469 ch	01.1993 > 02.2002
EUROSTAR - LD 260 E 52	514 ch	01.1993 > 02.2002
EUROSTAR - LD 400 E 38 TX/P,LD 440 E 38 TX/P	375 ch	01.1993 > 02.2002
EUROSTAR - LD 400 E 42 TX/P,LD 440 E 42 TX/P	420 ch	01.1993 > 02.2002
EUROSTAR - LD 440 E 38 T	375 ch	01.1993 > 02.2002
EUROSTAR - LD 440 E 38 TZ	375 ch	01.1993 > 02.2002
EUROSTAR - LD 440 E 42 T/P	420 ch	01.1993 > 02.2002
EUROSTAR - LD 440 E 42 TZ	420 ch	01.1993 > 02.2002
EUROSTAR - LD 440 E 47 T/P	469 ch	01.1993 > 02.2002
EUROSTAR - LD 440 E 47 TZ	469 ch	01.1993 > 02.2002
EUROSTAR - LD 440 E 52 T	514 ch	01.1993 > 02.2002
EUROSTAR - LD 440 E 52 TZ	514 ch	01.1993 > 02.2002
EUROTRAKKER - MP 190 E 30 H	301 ch	01.1993 > 11.2004
EUROTRAKKER - MP 190 E 30 W	301 ch	01.1993 > 11.2004
EUROTRAKKER - MP 190 E 34 H	345 ch	01.1993 > 11.2004
EUROTRAKKER - MP 190 E 34 W	345 ch	01.1993 > 11.2004
EUROTRAKKER - MP 190 E 37 H	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 190 E 37 W	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 190 E 42 H	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 190 E 42 W	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 260 E 30 H	301 ch	01.1993 > 11.2004
EUROTRAKKER - MP 260 E 34 H	345 ch	01.1993 > 11.2004
EUROTRAKKER - MP 260 E 34 W	345 ch	01.1993 > 11.2004
EUROTRAKKER - MP 260 E 37 H	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 260 E 37 W	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 260 E 42 H	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 260 E 42 W	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 340 E 34 H	345 ch	01.1993 > 11.2004
EUROTRAKKER - MP 340 E 37 H	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 340 E 42 H	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 380 E 37 H	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 380 E 37 W	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 400 E 34 HT	345 ch	01.1993 > 11.2004

<b>IVECO</b>		
EUROTRAKKER - MP 400 E 37 HT	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 400 E 37 WT	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 400 E 42 HT	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 400 E 42 WT	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 410 E 37 H	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 410 E 42 H	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 410 E 42 W	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 440 E 34 HT	345 ch	01.1993 > 11.2004
EUROTRAKKER - MP 440 E 42 HT	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 720 E 37 HT	370 ch	01.1993 > 11.2004
EUROTRAKKER - MP 720 E 42 HT	420 ch	01.1993 > 11.2004
EUROTRAKKER - MP 720 E 42 WT	420 ch	01.1993 > 11.2004
EUROTECH MP - 180 E 34	345 ch	01.1992 > 12.1993
EUROTECH MP - 180 E 38	375 ch	01.1992 > 12.1993
EUROTECH MP - 180 E 42	420 ch	01.1992 > 12.1993
EUROTECH MP - 190 E 34	345 ch	01.1993 >
EUROTECH MP - 190 E 38	375 ch	01.1993 >
EUROTECH MP - 190 E 42, 190 E 42 /P	420 ch	01.1993 >
EUROTECH MP - 240 E 30 PS	301 ch	01.1997 >
EUROTECH MP - 240 E 34	345 ch	09.1995 > 12.1996
EUROTECH MP - 240 E 38	375 ch	01.1992 >
EUROTECH MP - 240 E 42	420 ch	01.1992 >
EUROTECH MP - 260 E 38 P	375 ch	01.1994 >
EUROTECH MP - 260 E 42	420 ch	01.1994 >
EUROTECH MP - 400 E 34 T, 440 E 34 T	345 ch	01.1992 >
EUROTECH MP - 400 E 38 T, 440 E 38 T, 440 E 38 T /P	375 ch	01.1992 >
EUROTECH MP - 400 E 38 TXP	375 ch	11.1993 > 12.1996
EUROTECH MP - 440 E 38 TZ	375 ch	01.1993 >
EUROTECH MP - 400 E 42 T, 440 E 42 T, 440 E 42 T/P	420 ch	01.1992 >
EUROTECH MP - 440 E 42 TZ	420 ch	01.1993 >
EUROTECH MT - 180 E 24	239 ch	01.1992 > 12.1996
EUROTECH MT - 180 E 24 K	239 ch	01.1993 > 12.1996
EUROTECH MT - 180 E 27	267 ch	01.1992 > 12.1996
EUROTECH MT - 180 E 27 K	267 ch	01.1992 > 12.1996
EUROTECH MT - 180 E 30 R	301 ch	01.1992 > 12.1996
EUROTECH MT - 180 E 34 R	345 ch	01.1992 > 12.1993
EUROTECH MT - 190 E 24	239 ch	01.1997 > 08.1998
EUROTECH MT - 190 E 24 K	239 ch	01.1997 > 08.1998
EUROTECH MT - 190 E 27	267 ch	01.1997 > 08.1998
EUROTECH MT - 190 E 27 K	267 ch	01.1997 > 08.1998
EUROTECH MT - 190 E 30	301 ch	01.1997 > 08.1998
EUROTECH MT - 190 E 30 K	301 ch	01.1997 > 08.1998
EUROTECH MT - 400 E 30 T	301 ch	01.1992 > 08.1998
EUROTECH MT - 400 E 34 T	345 ch	01.1992 > 08.1998
TURBOTECH - 190-36	377 ch	01.1990 > 12.1992
TURBOTECH - 190-36 T	377 ch	01.1990 > 12.1992
TURBOTECH - 240-36 P	377 ch	01.1990 > 12.1992
TURBOSTAR - 190-36	377 ch	07.1990 > 12.1993
TURBOSTAR - 190-36 P	377 ch	07.1990 > 12.1993
TURBOSTAR - 190-36 T	377 ch	07.1990 > 12.1993
P/PA - 190-30 H	305 ch	04.1987 > 12.1990

<b>IVECO</b>		
	305 ch	01.1991 > 12.1992
P/PA - 190-30 HT	305 ch	01.1989 > 12.1990
	305 ch	01.1990 > 12.1992
P/PA - 190-30 H	305 ch	04.1987 > 12.1990
	305 ch	01.1991 > 12.1992
P/PA - 330-30 HT	305 ch	01.1988 > 12.1990
	305 ch	01.1991 > 12.1992
	305 ch	01.1988 > 12.1990
	305 ch	01.1988 > 12.1992
P/PA - 330-30 H	305 ch	01.1988 > 12.1990
	305 ch	01.1991 > 12.1992
	305 ch	06.1984 > 12.1990
	305 ch	06.1984 > 12.1992
P/PA - 330-36 HT	360 ch	01.1991 > 12.1992
	360 ch	01.1989 > 12.1992
P/PA - 330-36 H	360 ch	01.1991 > 12.1992
	360 ch	01.1989 > 12.1992
P/PA-Haubenfahrzeuge - 190-30 NT	305 ch	04.1987 > 12.1990
	305 ch	01.1991 > 12.1993
P/PA-Haubenfahrzeuge - 190-30 N	305 ch	04.1987 > 12.1990
	305 ch	01.1991 > 12.1993
P/PA-Haubenfahrzeuge - 330-30 N	305 ch	10.1987 > 12.1990
	305 ch	01.1991 > 12.1992
P/PA-Haubenfahrzeuge - 330-30 NW	305 ch	10.1987 > 12.1990
	305 ch	01.1991 > 12.1992