




Push Type Centralizers

After the clutch is fitted to the flywheel the centralizers need to be adjusted. The slider part of the centralizer needs to be contacting the flywheel. Using a punch, the centralizer sliders can be adjusted through holes located in the cover assembly. This must be done prior to installing the gearbox.











CLUTCH AND FLYWHEEL SPECIALISTS



Scan with a QR app on your smart phone













