



Assembly Instructions for Concentric Slave Cylinder CSCVW01

If for any reason the Concentric Slave Cylinder (CSC) has become separated from the release bearing, it is important that the bearing is re-fitted to the CSC correctly. Following these few steps will assist with this.





The release bearing has a guided ridge which seats in the CSC carrier. If the release bearing is fitted incorrectly the raised ridge will foul on the clutch cover causing the bearing to fail.





LEADING BRANDS





