



WARNING



Not following the instructions below may result in damage of the product supplied by us and refusal of the claim due to improper installation of the product.


THE FOLLOWING STEPS MUST BE CONDUCTED UNCONDITIONALLY:

1


Before starting the replacement process, it is necessary to find the cause of the damage to prevent re-damaging the newly installed part.

**2**

At the beginning it is recommended to check the cleanliness of the connections, they must not be contaminated with grease or sand.

**3**

Check that the connections and hoses are not damaged.

**4**


Fit the pump to the vehicle first and then proceed with fitting the hoses.

**5**


When mounting the pump, remove the protective cover before installing the hose to avoid contaminating other components.

**6**

Check the electronics connectors – they must not be damaged, defective, burnt, corroded, incomplete.

**7**

Plugs must also be complete.

**8**

If there are signs of electronics shorting, the wiring harness may be damaged.

