


FITTING INSTRUCTIONS FOR BYCO CABIN AIR FILTER BCA182P/MS MITSUBISHI OUTLANDER (ZG & ZH) (pictured), ALFA ROMEO 159, BRERA, SPIDER & MIITSUBISHI ASX (GA), LANCER (CJ)






The cabin air filter housing is located behind the glovebox. To gain acces, the glovebox has to first be removed. Remove objects from compartment and unclip the strut shown in pic above.

With the strut unclipped, proceed to release the glove box from its securing hinge. Simply apply some pressure to the far upper corners towards the inside of the compartment as indicated in the pic and slowly drop the unit.



With the glove box unit out of the way the housing will be easily identifiable sitting on top of the blower fan. Remove the housing lid and pull out the dirty filter and clean area from large objects trapped in the housing.



Insert the new filter in the right air flow direction. Look for arrow on one of the sides of the filter to identify air flow direction. Re-fit all components in reverse order.

Victoria 3025 Australia www.rycofilters.com.au

GUD Automotive Ptv Ltd GUD Automotive - A Division of 29 Taras Ave Altona North GUD (NZ) Holdings Limited 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz



FITTING INSTRUCTIONS FOR RYCO CABIN AIR FILTER RCA182P/MS MITSUBISHI OUTLANDER (ZG & ZH) (pictured), ALFA ROMEO 159, BRERA, SPIDER & MIITSUBISHI ASX (GA), LANCER (CJ)





The cabin air filter housing is located behind the glovebox. To gain acces, the glovebox has to first be removed. Remove objects from compartment and unclip the strut shown in pic above.

With the strut unclipped, proceed to release the glove box from its securing hinge. Simply apply some pressure to the far upper corners towards the inside of the compartment as indicated in the pic and slowly drop the unit.





With the glove box unit out of the way the housing will be easily identifiable sitting on top of the blower fan. Remove the housing lid and pull out the dirty filter and clean area from large objects trapped in the housing.

Insert the new filter in the right air flow direction. Look for arrow on one of the sides of the filter to identify air flow direction. Re-fit all components in reverse order.

GUD Automotive Ptv Ltd GUD Automotive - A Division of Victoria 3025 Australia www.rycofilters.com.au

29 Taras Ave Altona North GUD (NZ) Holdings Limited 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz

INSTRUCTION SHEET IS182P ISS 2