

1. The cabin air filter is located behind the glove box compartment unit.

2. Open the glove box and press both top corners inwards to bypass the retaining lugs allowing the lid to drop completely.

3. Remove the cabin air filter housing lid by unclipping it and slide out the old cabin air filter carefully to avoid any accumulated debris from being spread around

4. Slide in the new filter making sure it is facing to the right air flow direction and refit all components in reverse order.

GUD Automotive Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au GUD Automotive -A division of GUD (NZ) Holdings Limited 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz