PIERBURG

2.10
Reading out the fault code memory – diagnostic process

connection of the scan tool to the diagnostic connection in the vehicle	⚠ **Attention:** connection only when ignition is OFF!
automatic detection of the type of transmission used by the control unit	switch ignition on
communication setup	After successful communication setup the system identified will be displayed with the system identification and address.
selection of the desired test mode	please refer to section 2.11
reception of the data requested	