




Tightening torque


Centred around wheel bolt / front axles

Stage 1 = 60 Nm
Stage 2 = 300 Nm




Centred around centre / front axles

Stage 1 = 60 Nm
Stage 2 = 500 Nm




Centred around wheel bolt / rear axles

Stage 1 = 60 Nm
Stage 2 = 300 Nm



Centred around centre / rear axles

Stage 1 = 60 Nm
Stage 2 = 500 Nm



Please check tightening torques regularly !

Use a torque spanner to ensure that the specified torques are accurately maintained.

If the wheels were off, check and re-tighten the wheel nuts after about 200 km of driving.

