




Tightening torque

Centred around wheel bolt / front axles

Stage 1 = 60 Nm


Stage 2 = 450 Nm



Centred around wheel bolt / rear axles

Stage 1 = 60 Nm

Stage 2 = 450 Nm



Please check tightening torques regularly !

Use a torque spanner to ensure that the specified torques are accurately maintained.

If the wheels were off, check and re-tighten the wheel nuts after about 200 km of driving.

