



Releasers with metal bodies will be replaced by releasers with plastic bodies.



Fig. 1: Releaser with metal body



Fig. 2: Releaser with plastic body

Due to advances in technology, releasers with metal bodies (Fig. 1) will be superseded by releasers with a plastic body and plastic slide sleeve (Fig. 2).

Metal slide sleeves will be replaced by plastic slide sleeves.



Fig. 3: Releaser with metal slide sleeve



Fig. 4: Releaser with plastic slide sleeve

Due to advances in technology, releasers with metal slide sleeve (Fig. 3) will be superseded by releasers with plastic slide sleeve (Fig. 4).



Do **not** grease releasers with plastic slide sleeves!
The lubrication nipple is located in the bellhousing.
Remove or blank off the lubrication nipple.



www.zf.com/serviceinformation